# 1702 EASYPRINT



Class 2



#### **CARRIER:** Transparent Polyester

#### APPLIES ON

- ☆ Cotton
- ☆ Acrylic & Similar Fabrics

### CARE

- Always respect the garment's instructions
- Allow 24 hours after application before washing
- Iron the backside only

## WASH

- Max 140°F
- Preferably inside out
- Do NOT bleach
- Tumble-dry
- Do NOT Dry-clean

#### STORE

- Up to 1 year
- In a dry room (60-75°F)
- Away from sunlight
- In vertical position, in a plastic bag protected from dust

# **APPLICATION**

- 1. Prepare your design right-reading (DO NOT MIRROR) following the instruction of the printer manufacturer. NOTE: It is recommended to use OEM printer inks. Printable medias are very sensitive: always handle with care, preferably with gloves.
- 2. Set your printing temperature to 45°C and drying temperature to 50°C.
- 3. Use the adequate printing profile (for instance, with Roland COLORIP or VersaWorks, select the profile GENERIC VINYL 1, and we recommend to select the option MAX IMPACT).
- 4. Remove the product from the printer and wait for the complete drying of inks at room temperature, at least 4 hours.
- 5. Weed the excess material.
- 6. The use of application tape is optional. It is possible to transfer your design by hand or with a clear polyester application tape. Do not use a paper application tape.
- 7. Position and heat press your design on the garment protected by a silicone paper at 320°F–20 seconds medium pressure.
- 8. If you used tape, peel peel it off when hot.

